



- * DENOTES CONTINUOUS SUPPORT STRUCTURE NOT BY KALWALL INSTALLER
- ⊗ DENOTES ADJUSTMENT SHIMS TO BE SUPPLIED BY KALWALL INSTALLER TO ACCOMMODATE SECONDARY STEEL TOLERANCES, ENGINEER TO ADVISE TOLERANCES.